


LEDLENSER Flex10




USB A To Type-C

1


Input port (Micro USB)

Lock-Unlock Wheel





Power Button

Input/Output port (Type-C)




3


1x click



4




5



1.

2.



New 21700





3.



21700

4.



Ledlenser Product

2




.....





Output port (USB-A)


Input/Output port (Type-C)



Off



discharging




4

USB charging cable


Input port (Micro USB)

Input/Output port (Type-C)







PC

charging



LEDLENSER Flex10



Ledlenser GmbH & Co. KG
 Kronenstrasse 5-7 • 42699 Solingen • Germany
 Phone +49 212/5948-0 Fax +49 212/5948-200
 info@ledlenser.com



1J12A0407
 Flex10 QUG_V0
 2021.03.03