



Yellow  
Yellow

DURABLE  
**WALL & FLOOR**  
**TILE GROUT**  
PRE-MIX

# HOW TO USE?

QUICK GUIDE

## Step 1

Select the right grout for the job.



## Step 2

Add water to grouting powder in the ratio 2:1

2 PORTION OF  
POWDER

1 PORTION OF  
WATER

## Step 3

Tilt mixing bucket and stir with a grout-mixing knife.

## Step 4

Adjust grout consistency by adding more powder or water.



## Step 5

Let grout rest (slake) for up to 10 minutes.



10 mins

## Step 6

Apply with a screeding trowel.



## Step 7

Leave the curing time up to 4 hours.



4 hours

## Step

Clean up area with a wet sponge.



VISIT [WWW.HARDWARECITY.COM.SG](http://WWW.HARDWARECITY.COM.SG) FOR MORE